



DVDUUBS

DVDU CONVERSION KIT FOR ROUND TUBE ARMS

MATERIAL LIST	
DESCRIPTION	QTY
5/16" UBOLT 1-5/8" I.D.	1
1-5/8" UBOLT SADDLE	1
5/16" NYLON LOCK NUT	2
5/16" FLAT WASHER	2

1. Attach DVD support rails to side arms using smaller acorn nuts.
2. Insert side arms into center channel.
3. Place and center DVD on support channels. Mark location of side arms on side of DVD.
4. Insert carriage bolts through slots in side arms and square holes in center channel. Use two carriage bolts on each side of center channel when possible. Place a washer, lock washer, and acorn nut on each carriage bolt and loosely tighten the acorn nuts.
5. Remove DVD from mount.
6. Position DVDU mount beneath TV mount. Attach with U-Bolt and nylon lock nuts.
7. Clean sides of DVD with isopropyl alcohol three times and wipe dry to provide clean surface for adhesive.
8. Remove protective paper from adhesive pads on the DVD support rails.
9. Insert the DVD between the side arms and align the support rails with the centering marks on the sides of the DVD. Press the support lips against the sides of the DVD and maintain pressure for approximately 10 seconds.
10. Securely tighten acorn nuts on center channel.