



"ST" GUIDE

Safety Strap Retainer for ST20

Preparation: Rubber connectors require a flat solid surface for bonding. Abrade contact areas with fine sandpaper disc. Thoroughly clean abraded areas and surfaces of rubber connectors with isopropyl alcohol pad. Dry surfaces with paper towels.

1. Read **CAUTION** statement on Permabond tube label before proceeding. Unscrew applicator tip from Permabond tube. Remove collar from neck of tube. Screw applicator tip back onto tube to puncture metal membrane in tube neck.
2. Remove cover from applicator tip. Place eight drops of Permabond adhesive on each rubber connector.
3. Use the applicator tip to smooth the drops into a neat circle. Replace cover on applicator tip.
4. Attach rubber connectors to TV in desired area. Apply pressure to connectors for ten seconds. Allow twenty-four hours for Permabond to set.
5. Place strap through strap retainer. Refer to ST instructions for securing strap.

Protected under one or more of these U.S. Patent numbers: 3,291,432 3,559,942 3,724,798 DES:270,689 4,613,109 4,878,645 4,852,842 DES:309,562 4,973,023 5,169,114 5,255,884 5,310,152 5,522,576 5,621,614 Re:35,677 DES:398,834 5,826,384 5,941,492 5,964,068 6,060,661 6,102,398