LUCASEY MOUNTING SYSTEMS

LC200WA2 Wall Mount for Flat Panel Screens up to 32" with up to 200mm x 200mm VESA Mounting Patterns





1. Remove the 5/16" Hex Bolt from the Wall Arm. Set aside the VESA Plate and hardware for Step 9.

2. Remove the Covers and the 3/8" Hex Bolt from the Wall Plate. Set aside the Covers and hardware for Step 5.

3. Use the Wall Plate as a template to mark and drill 1/8" pilot holes for each of the Lag Screw locations. Check to make sure the Wall Plate is level before marking and drilling the pilot holes. Drill the top and bottom holes first. Then, drill the middle pilot hole with the Wall Plate level. (If installing in metal studs a hardware kit can be purchased separately, WMATB3.)

4. Use the provided Lag Screws to securely fasten the Wall Plate to the wall. Tighten the top and bottom screws before tightening the middle screw to allow for some adjustment to make the Wall Plate level.

5. Replace the 3/8" Hex Bolt and Covers. Test the Wall Arm to make sure the Wall Plate is holding securely.

Hardware List

#14 x 2-1/2" HWH Lag Screws 3
3/8-16 x 4-1/2" Hex Bolt 1
3/8" Flat Washers 7
3/8-16 Nylock Jam Nut 1
1/2" Caps 3
5/16-18 x 2-1/4" Hex Bolt 1
5/16" Flat Washers 2
5/16-18 Nylock Nut 2
5/16-18 x 1-1/2" Socket Button Head Screw 1
5/16" Belleville Washer 2
1/4-20 x 1-1/2" Socket Button Head Screw 1
1/4" Belleville Washer 4
1/4-20 Nylock Nut 1
#8-32 x 1/2" Phillips Self Tapping Screws 4

4mm x 25mm Set Screws	... 6	4mm Hex Nuts	... 12
5mm x 30mm Set Screws	... 6	5mm Hex Nuts	... 12
6mm x 30mm Set Screws	... 6	6mm Hex Nuts	... 12
4mm x 12mm Phillips Screws	... 6	5mm Flat Washers	... 36
5mm x 12mm Phillips Screws	... 6	1/4" Flat Washers	... 18
6mm x 12mm Phillips Screws	... 6		

Protected under one or more of these U.S. Patent numbers: 3,291,432 3,559,942 3,724,798 DES.270,689 4,613,109 4,878,645 4,852,842 DES.309,562 4,973,023 5,169,114 5,255,884 5,310,152 5,522,576 5,621,614 Re.35,677
DES.398,834 5,826,384 5,941,492 5,964,068 6,060,661 6,102,398 6,158,704 6,454,116B1 6,761,276B2 6,806,425B1

©2007 Lucasey Manufacturing Corporation, Oakland, California

LUCASEY MOUNTING SYSTEMS

LC200WA2 Wall Mount for Flat Panel Screens up to 32" with up to 200mm x 200mm VESA Mounting Patterns



6. Attach the monitor to the VESA Plate using hardware appropriate for the threaded inserts on the monitor as specified by the manufacturer. Several sizes of monitor attaching hardware have been provided for convienience.

7. Tighten the Tilt Plate Socket Button Head Screws to prevent the monitor from tilting initially.

8. Align the hole on the Swivel Plate with hole on the Wall Arm.

CAUTION! For larger monitors, installation requires at least two people to align the monitor and insert the 5/16" Hex Bolt. Attempting this installation without assistance may result in accidental damage to the monitor.

9. Replace the 5/16" Hex Bolt, washers, nylock nut and cap used in Step 1.

10. Tighten the 5/16" Hex Bolt and Button Head Screws to provide the desired tilting viewing angle and monitor position.

CAUTION! Do not leave the 5/16" Hex Bolt and Button Head Screws loose to prevent the Monitor from accidentally becoming damaged from movement.

Protected under one or more of these U.S. Patent numbers: 3,291,432 3,559,942 3,724,798 DES.270,689 4,613,109 4,878,645 4,852,842 DES.309,562 4,973,023 5,169,114 5,255,884 5,310,152 5,522,576 5,621,614 Re.35,677 DES.398,834 5,826,384 5,941,492 5,964,068 6,060,661 6,102,398 6,158,704 6,454,116B1 6,761,276B2 6,806,425B1

©2007 Lucasey Manufacturing Corporation, Oakland, California